

Whisper[®]

ULTRASONIC LEAK DETECTOR

Can you hear the leak? We can.

Whisper uses ultrasonic technology to listen for the sound of a gas moving through a leak site, making it a super versatile tool for leak checking ANY gas in pressurized or vacuum systems.

The optional accessory kit adds even more functionality, allowing for leak checking of door seals, ducts, steam traps, and mechanical parts like bearings. With its wide range of applications, Whisper is a great tool to have on hand.



WATCH
OUR VIDEO!



**NOW WITH
LASER
POINTER!**

SPECIFICATIONS

| | |
|-------------------------------------|--|
| Whisper includes | Whisper Headphones Rubber extension probe Two D-size alkaline batteries Carrying case |
| Whisper with accessory kit includes | Whisper Premium headphones Metal contact probe Whisper Transmitter (with battery) Rubber extension probe Two D-size alkaline batteries Carrying case |
| Power source | Two D-size alkaline batteries |
| Battery life | 165 hours (laser pointer off) 115 hours (laser pointer on) |
| Weight | 1.06 lb. (482 g) |
| Certifications | A2L Certified CE, UKCA |
| Warranty | Two-year over-the-counter |

ORDERING INFORMATION

| | |
|--|------------|
| Whisper | 711-202-G1 |
| Whisper with accessory kit includes | 711-203-G1 |
| Accessories and Replacement Parts | |
| Headphones | 032-0430 |
| Premium headphones | 032-0427 |
| Whisper Transmitter | 711-600-G1 |
| Contact probe | 711-703-G1 |
| Carrying case | 711-701-G1 |



- Accessory kit includes:
- Premium headphones
 - Hard metal probe for checking mechanical parts like worn bearings
 - Whisper Transmitter for checking door and window seals

ADVANTAGES

- Detects pressure and vacuum leaks for all gases
- Works even in noisy environments
- Laser pointer makes it easier to pinpoint the leak
- Applications include pressure/vacuum leaks, electrical arcing, malfunctioning steam traps and more!
- Only technology to detect pressurized nitrogen leaks
- Rugged carrying case included

